

Using Stream Deck with Rapidmooc

Version 1.0 – July 2021

Table of content

Introduction	3
Prerequisites	3
Connecting the Stream Deck to the Rapidmooc studio	3
Installing the Stream Deck software	3
Set up your keyboard shortcuts	5

Introduction

stream deck is a customizable usb control panel for triggering actions in Windows applications.

When used with a Rapidmooc studio, this makes the most common actions (such as pause, start, stop) more accessible and easier to use for the speaker.

Prerequisites

The Rapidmooc studio must be connected to the internet for the installation procedure.

Connecting the Stream Deck to the Rapidmooc studio

The Stream Deck device has a usb cable that you can plug into the back of the Rapidmooc studio.

Windows will then automatically detect Stream Deck and install the USB driver.


Installing the Stream Deck software

The stream deck software is required to associate actions with keys.


Open a browser and navigate to the address below:

Downloads | elgato.com


Then select the Stream Deck and Windows operating system as below. Click on the Show all button.




Scroll down the page until you find the Stream Deck application. Click on the "For Windows, version 5.0.1" button to start downloading.



Once the download is complete, open the download folder with the file explorer and start the installation program.



Follow the instructions to complete the installation process.



The stream deck application will launch automatically at the end of the installation.

Set up your keyboard shortcuts


The Stream Deck application window is divided into two parts: on the left the buttons of your control panel and on the right the possible actions.

Stream Deck	-	□ ×
Stream Deck Mini V Default Profile V	∨ (▶) Game Capture	
	🚊 Scene	
	🔞 Record	
	Screenshot	
	No. Flashback Recording	
	🐼 Stream	
WELCOME	🕴 Live Commentary	
	🚊 Scene	
	‡≪t) Mixer Audio	
	⊌ Stream	
	Source	
Drag an action from the right and drop it on an empty key above.	✓ ◀I Soundboard	
	Stop Audio	
	V Stream Deck	

Scroll down on the left side until you reach the System actions.Drag and drop the hotkey action onto one of the control panel keys.

Stream Deck			- 0	×
Stream Deck Mini ~ Default Profile ~	≣ ∲			:≡
		¦iet) Mixer Audio		
		🛞 Stream		
		Source		
		∨ 📑 System		
		🕀 Website		
	ME	🔳 Hotkey Swi		
		💽 Hotkey	Too Jetwe	een two k
		🚀 Open		
		▶() Multimedia		l
		~ 🎔 Twitter		
		🗭 Tweet		
Drag an action from the right and drop it on an empty key above.				
		✓ ➢ Control Cer	nter	
		U On / Off		
		🤘 Set Brightn	255	

Then select the keyboard shortcut to be associated with the button. The example below configures the space bar shortcut to pause the teleprompter.



Once the keyboard shortcuts have been configured, leave the Stream Deck application.

Then launch the Rapidmooc application to test that the stream deck buttons work properly.